

# INTERFACE SPECIFICATION

KNX CONVERTOR  
UTY-VKSX


PART NO. 9708438061

FUJITSU GENERAL LIMITED

# Contents

<b>1 SYSTEM OUTLINE</b> .....	<b>1</b>
<b>2 DIMENSION</b> .....	<b>2</b>
<b>3 SPECIFICATION</b> .....	<b>3</b>
3-1. Operating Environment .....	3
3-2. Transmission (Hardware) .....	3
3-3. Function .....	4
<b>4 CONFIGURATION AND SETUP</b> .....	<b>4</b>
<b>5 ETS PARAMETERS</b> .....	<b>5</b>
5-1. Mode dialog.....	5
5-2. Temperature dialog .....	8
5-3. Air Flow dialog.....	9
5-4. Vertical Air Direction dialog .....	11
5-5. Horizontal Air Direction dialog .....	14
5-6. Centrally Control dialog.....	17
5-7. Energy Saving dialog .....	18
5-8. Additional Function dialog .....	20
5-9. Specific status monitoring dialog.....	20
5-10. Scene Configuration dialog .....	21
5-11. Convertor Information dialog .....	24
<b>6 COMMUNICATION OBJECTS TABLE</b> .....	<b>26</b>

# 1 SYSTEM OUTLINE



## (1) What is the KNX Convertor ?

The convertor for connecting our Indoor Unit to the system built by KNX, an open network, to manage the Indoor Unit.


## (2) Maximum Connectable number per 1 KNX Convertor.

Indoor Unit	1
-------------	---

## 2 DIMENSION

The KNX convertor is comprised of a body and cover.

Unit : mm (in)



### 3 SPECIFICATION

#### 3-1. Operating Environment

Power consumption (W)		0.6
Temperature °C (°F)	Operating	0–46 (32–114)
	Packaged	-10–60 (14–140)
Humidity (%)	Packaged	0–95 (RH); No condensation
Dimensions H × W × D mm (in)		43 x 117 x 140 (1-11/16 x 4-5/8 x 5-1/2)
Weight g (oz)		215 (8)

#### 3-2. Transmission (Hardware)

Use	Size		Wire type	Remarks
KNX cable	Maximum	0.8 mm <sup>2</sup> (18AWG)	AWG18-20 2wire twisted pair	KNX TP1 (Twister Pair 1) cable
	Minimum	0.5 mm <sup>2</sup> (20AWG)		

### 3-3. Function

Item* <sup>1</sup>	Control* <sup>2</sup>	Monitor Information* <sup>3</sup>	Convertor
	Indoor Unit	Indoor Unit	
ON/OFF command	●	●	
Operation mode setting	●	●	
Temperature setting	●	●	
Airflow mode setting	●	●	
Thermostat off setting	●	●	
Centrally control (Filter reset)	●	●	
Centrally control (All mode)	●	●	
Centrally control (Timer mode)	●	●	
Centrally control (Set temperature mode)	●	●	
Centrally control (ON/OFF mode)	●	●	
Centrally control (ON mode)	●	●	
Centrally control (Operation mode)	●	●	
Filter sign reset	●	●	
Energy save mode setting	●	●	
Vertical/horizontal airflow direction louver setting	●	●	
Room temperature		●	
Error status / Error code		●	●
Specific status		●	
Model name			●
Software version			●
Demand status		●	
Human detection auto save	●	●	
Human detection auto off	●	●	
Scene control	●	●	

\*<sup>1</sup> Refer to the product manuals for each function.

\*<sup>2</sup> KNX network → Indoor Unit

\*<sup>3</sup> Indoor Unit → KNX network

## 4 CONFIGURATION AND SETUP

This is a fully compatible KNX device which must be configured and setup using standard KNX tool ETS. ETS database for this device can be downloaded from:

<http://fujitsu-general.com/global/support/downloads/split/index.html>

## 5 ETS PARAMETERS

When imported into the ETS software for the first time, the default parameter configuration of the gateway is shown below:

15.15.255 KNX Converter for Indoor > Mode	
<b>Mode</b>	Enable use of 8-bit unsigned value object (for Setting and Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	
Air Flow	Enable use of bit-type objects (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Vertical Air Direction	Enable use of bit-type objects (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	Enable use of +/- object (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Centrally Control	
Energy Saving Function	Enable use of Text object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Support Function	
Specific status monitoring	
Scene	
Convertor Information	

In this configuration, the operation mode (Setting\_Operation Mode), operation on/off (Setting\_Operation ON/OFF), set temperature (Setting\_Set Temperature), and airflow (Setting\_Airflow) settings can be configured.

Monitoring objects can monitor the status of operation mode (Monitoring\_Operation Mode), operation on/off (Monitoring\_Operation ON/OFF), set temperature (Monitoring\_Set Temperature), airflow (Monitoring\_Airflow), room temperature (Monitoring\_Room Temperature), and error (Monitoring\_Error Status).

1	Inner_Setting_Operation Mode [HVAC]	0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
9	Inner_Setting_Operation On/Off	0 - Off; 1 - On
10	Inner_Setting_Set Temperature	(°C)
12	Inner_Setting_Airflow	0%-13% - Auto; 14%-27% - Quiet; 28%-41% - Low; 42%-55% - Med-Low; 56%-70% - Med; 71%-85% - Med-High; 86%-100% - High
55	Inner_Monitoring_Operation Mode [HVAC]	0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
63	Inner_Monitoring_Operation On/Off	0 - Off; 1 - On
64	Inner_Monitoring_Set Temperature	(°C)
65	Inner_Monitoring_Airflow	13% - Auto; 27% - Quiet; 41% - Low; 55% - Med-Low; 70% - Med; 85% - Med-High; 100% - High
74	Inner_Monitoring_Room Temperature	(°C)
75	Inner_Monitoring_Error Status Error/No error	0 - No error; 1 - Error
76	Inner_Monitoring_Error Status Error Code	(Error code section)(Error code subsection)

### 5-1. Mode dialog

15.15.255 KNX Converter for Indoor > Mode	
<b>Mode</b>	Enable use of 8-bit unsigned value object (for Setting and Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	
Air Flow	Enable use of bit-type objects (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Vertical Air Direction	Enable use of bit-type objects (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	Enable use of +/- object (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Centrally Control	
Energy Saving Function	Enable use of Text object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Support Function	
Specific status monitoring	
Scene	
Convertor Information	

All the parameters in this section are related with the different mode properties and communication objects.

### 5-1-1. Enable use of 8-bit unsigned value object

This parameter shows/hides the 8-bit unsigned value Setting\_ and Monitoring\_ Operation Mode communication objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the 8-bit unsigned value Setting\_ and Monitoring\_ Operation Mode objects will appear. Fields to select the DPT setting will also appear.

Enable use of 8-bit unsigned value object (for Setting and Monitoring)  No  Yes

> DPT selection  Scaling  Enumerated

### 5-1-2. DPT object type for Operation Mode objects

This parameter changes the DPT setting of the 8-bit unsigned value Setting\_ and Monitoring\_ Operation Mode objects. For datapoints, Scaling and Enumerated are selectable.

- When “Enumerated” is selected, Setting\_ and Monitoring\_ Operation Mode communication objects for this DPT will appear.

■ 2 Inner\_Setting\_ Operation Mode 1 - Auto; 2 - Heat; 3 - Cool; 4 - Fan; 5 - Dry

■ 56 Inner\_Monitoring\_ Operation Mode 1 - Auto; 2 - Heat; 3 - Cool; 4 - Fan; 5 - Dry

- When “Scaling” is selected, Setting\_ and Monitoring\_ Operation Mode communication objects for this DPT will appear.

■ 2 Inner\_Setting\_ Operation Mode 0%-20% - Auto; 21%-40% - Heat; 41%-60% - Cool; 61%-80% - Fan; 81%-100% - Dry

■ 56 Inner\_Monitoring\_ Operation Mode 20% - Auto; 40% - Heat; 60% - Cool; 80% - Fan; 100% - Dry

Table next shows the range of values that can be sent through the Setting\_ object and the value returned by the Monitoring object.

	Auto	Heat	Cool	Fan	Dry
Setting_	0% - 20%	21% - 40%	41% - 60%	61% - 80%	81% - 100%
Monitoring_	20%	40%	60%	80%	100%

### 5-1-3. Enable use of bit-type Operation Mode objects (for setting)

This parameter shows/hides the bit-type Setting\_ Operation Mode objects.

■ 3 Inner\_Setting\_ Operation Mode Auto 1 - Auto

■ 4 Inner\_Setting\_ Operation Mode Heat 1 - Heat

■ 5 Inner\_Setting\_ Operation Mode Cool 1 - Cool

■ 6 Inner\_Setting\_ Operation Mode Fan 1 - Fan

■ 7 Inner\_Setting\_ Operation Mode Dry 1 - Dry

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ Operation Mode objects for Auto, Heat, Cool, Fan and Dry will appear. When enabled, a mode will return a “1” through its bit-type object.

### 5-1-4. Enable use of bit-type Operation Mode objects (for monitoring)

This parameter shows/hides the bit-type Monitoring\_ Operation Mode objects.

■ 57 Inner\_Monitoring\_ Operation Mode Auto 1 - Auto

■ 58 Inner\_Monitoring\_ Operation Mode Heat 1 - Heat

■ 59 Inner\_Monitoring\_ Operation Mode Cool 1 - Cool

■ 60 Inner\_Monitoring\_ Operation Mode Fan 1 - Fan

■ 61 Inner\_Monitoring\_ Operation Mode Dry 1 - Dry

- If set to “No” the objects will not be shown.




- If set to “Yes” the bit-type Monitoring\_ Operation Mode objects for Auto, Heat, Cool, Fan and Dry will appear. When enabled, a mode will return a “1” through its bit-type object.

### 5-1-5. Enable use of +/- object for Operation Mode (for setting)

This parameter shows/hides the Setting\_ Operation Mode +/- communication object which lets change the indoor unit mode.

```
Inner_Setting_ Operation Mode +/- 0 - Up; 1 - Down
```

- If set to “No” the object will not be shown.
- If set to “Yes” the Setting\_ Operation Mode +/- object will appear.
- DPT type for +/- Operation Mode Object  
The sequence followed when using this object is shown below:



### 5-1-6. Enable use of Text object for Operation Mode (for Monitoring)

This parameter shows/hides the Monitoring\_ Operation Mode Text communication object.

```
Inner_Monitoring_ Operation Mode Text ASCII String
```

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Operation Mode Text object will appear. Also, in the parameters, will be shown five text fields, one for each mode, that will let modify the text string displayed by the Monitoring\_ Operation Mode Text when changing mode.

Enable use of Text object (for Monitoring)  No  Yes

> String when mode is Auto	<input type="text" value="AUTO"/>
> String when mode is Cool	<input type="text" value="COOL"/>
> String when mode is Heat	<input type="text" value="HEAT"/>
> String when mode is Dry	<input type="text" value="DRY"/>
> String when mode is Fan	<input type="text" value="FAN"/>

## 5-2. Temperature dialog

15.15.255 KNX Converter for Indoor > Temperature

Mode	Enable use of +/- object (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
<b>Temperature</b>	
Air Flow	Transmission of "Monitoring_Room Temperature" <span style="float: right;">Only on Change ▼</span>
Vertical Air Direction	
Horizontal Air Direction	
Centrally Control	
Energy Saving Function	
Support Function	
Specific status monitoring	
Scene	
Convertor Information	

### 5-2-1. Enable use of +/- object for Set Temperature (for setting)

This parameter shows/hides the Setting\_ Set Temperature +/- communication object which lets change the indoor unit set-point temperature.

11 Inner\_Setting\_Set Temperature +/- 0 - Up; 1 - Down

- If set to "No" the object will not be shown.
- If set to "Yes" the Setting\_ Set Temperature +/- object will appear.
- DPT type for +/- Set Temperature Object

The sequence followed when using this object is shown below:



### 5-2-2. Transmission of "Monitoring\_Room Temperature"

This parameter lets to you choose if the room temperature will be sent "Only on Change", "Only cyclically" or "On change and Cyclically".

74 Inner\_Monitoring\_Room Temperature (°C)

Transmission of "Monitoring_Room Temperature"	<div style="border: 1px solid #ccc; padding: 2px;"> <span style="float: right;">▼</span> </div> <div style="border: 1px solid #ccc; padding: 2px;"> <span style="float: right;">✓</span> </div>
	<ul style="list-style-type: none"> <li>Only on Change</li> <li>Only cyclically</li> <li>On change and Cyclically</li> </ul>

- If set to "Only cyclically" or "On change and Cyclically" cyclic sending will appear.
- If "Only cyclically" or "On change and Cyclically" is set, cyclic sending of "Monitoring\_Room Temperature" will appear.

### 5-2-3. Cyclic sending of “Monitoring\_ Room Temperature”

This parameter will only be available for the “only cyclically” and “cyclically and on change” options, and lets you change the interval of time (in seconds, from 1 to 255) at the end of which the room temperature is sent to the KNX bus.

### 5-3. Air Flow dialog

15.15.255 KNX Convertor for Indoor Unit > Air Flow

Mode	DPT selection	<input checked="" type="radio"/> Scaling <input type="radio"/> Enumerated
Temperature	Enable use of bit-type objects (for Setting)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Air Flow		
Vertical Air Direction	Enable use of bit-type objects (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	Enable use of +/- object (for Setting)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Centrally Control	Enable use of Text object (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Energy Saving Function		
Support Function		
Specific status monitoring		
Scene		
Convertor Information		

All the parameters in this section are related with the different air flow properties and communication objects.

#### 5-3-1. DPT object type for Air Flow objects

This parameter changes the DPT setting of the 8-bit unsigned value Setting\_ and Monitoring\_ Air Flow objects. For datapoints, Scaling and Enumerated are selectable.

- When “Enumerated” is selected, Setting\_ and Monitoring\_ Air Flow communication objects for this DPT will appear.

	12 Inner_Setting_Airflow	1 - Auto; 2 - Quiet; 3 - Low; 4 - Med-Low; 5 - Med; 6 - Med-High; 7 - High
	65 Inner_Monitoring_Airflow	1 - Auto; 2 - Quiet; 3 - Low; 4 - Med-Low; 5 - Med; 6 - Med-High; 7 - High

- When “Scaling” is selected, Setting\_ and Monitoring\_ Air Flow communication objects for this DPT will appear.

	12 Inner_Setting_Airflow	0%-13% - Auto; 14%-27% - Quiet; 28%-41% - Low; 42%-55% - Med-Low; 56%-70% - Med; 71%-85% - Med-High; 86%-100% - High
	65 Inner_Monitoring_Airflow	13% - Auto; 27% - Quiet; 41% - Low; 55% - Med-Low; 70% - Med; 85% - Med-High; 100% - High

Table next shows the range of values that can be sent through the Setting\_ object and the value returned by the Monitoring\_ object.

	Auto	Quiet	Low	Med-Low	Med	Med-High	High
Setting_	0% - 13%	14% - 27%	28% - 41%	42% - 55%	56% - 70%	71% - 85%	86% - 100%
Monitoring_	13%	27%	41%	55%	70%	85%	100%

### 5-3-2. Enable use of bit-type Air Flow objects (for setting)

This parameter shows/hides the bit-type Setting\_ Air Flow objects.

13	Inner_Setting_Airflow Auto	1 - Auto
14	Inner_Setting_Airflow Quiet	1 - Quiet
15	Inner_Setting_Airflow Low	1 - Low
16	Inner_Setting_Airflow Med-Low	1 - Med-Low
17	Inner_Setting_Airflow Med	1 - Med
18	Inner_Setting_Airflow Med-High	1 - Med-High
19	Inner_Setting_Airflow High	1 - High

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ Air Flow objects for Auto, Quiet, Low, Med-Low, Med, Med-High and High will appear. To activate an air flow by using these objects a “1” value has to be sent.

### 5-3-3. Enable use of bit-type Air Flow objects (for monitoring)

This parameter shows/hides the bit-type Monitoring\_ Air Flow objects.

66	Inner_Monitoring_Airflow Auto	1 - Auto
67	Inner_Monitoring_Airflow Quiet	1 - Quiet
68	Inner_Monitoring_Airflow Low	1 - Low
69	Inner_Monitoring_Airflow Med-Low	1 - Med-Low
70	Inner_Monitoring_Airflow Med	1 - Med
71	Inner_Monitoring_Airflow Med-High	1 - Med-High
72	Inner_Monitoring_Airflow High	1 - High

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Monitoring\_ Air Flow objects for Auto, Quiet, Low, Med-Low, Med, Med-High and High will appear. When enabled, an air flow will return a “1” through its bit-type object.


### 5-3-4. Enable use of +/- object for Air Flow (for setting)

This parameter shows/hides the Setting\_ Air Flow +/- communication object which lets change the indoor unit air flow.

20	Inner_Setting_Airflow +/-	0 - Up; 1 - Down
----	---------------------------	------------------

- If set to “No” the object will not be shown.
- If set to “Yes” the Setting\_ Air Flow +/- object will appear.
- DPT type for +/- Air Flow Object

The sequence followed when using this object is shown below:



### 5-3-5. Enable use of Text object for Air Flow (for Monitoring)

This parameter shows/hides the Monitoring\_ Air Flow Text communication object.

73 Inner\_Monitoring\_Airflow Text ASCII String

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Air Flow Text object will appear.  
Also, in the parameters, will be shown seven text fields, one for each air flow, that will let modify the text string displayed by the Monitoring\_ Air Flow Text when changing air flow.

Enable use of Text object (for Monitoring)  No  Yes

> String when airflow is Auto	AUTO
> String when airflow is Quiet	QUIET
> String when airflow is Low	LOW
> String when airflow is Med-Low	MED-LOW
> String when airflow is Med	MED
> String when airflow is Med-High	MED-HIGH
> String when airflow is High	HIGH

### 5-4. Vertical Air Direction dialog

15.15.255 KNX Converter for Indoor > Vertical Air Direction

Mode	Enable use of Vertical Air Direction object (for Setting and Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	
Air Flow	

**Vertical Air Direction**

Horizontal Air Direction
Centrally Control
Energy Saving Function
Support Function
Specific status monitoring
Scene
Convertor Information

All the parameters in this section are related with the different vertical air direction properties and communication objects.

### 5-4-1. Enable use of Vertical Air Direction objects (for Setting and Monitoring)

This parameter shows/hides the Setting\_ and Monitoring Vertical Air Direction objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the 8-bit unsigned value Setting\_ and Monitoring\_ Vertical Air Direction objects will appear. Also, the field to select the DPT setting and field to set the Vertical Air Direction object setting will appear.

15.15.255 KNX Converter for Indoor Unit > Vertical Air Direction

Mode	Enable use of Vertical Air Direction object (for Setting and Monitoring)	<input type="radio"/> No <input checked="" type="radio"/> Yes
Temperature	DPT selection	<input checked="" type="radio"/> Scaling <input type="radio"/> Enumerated
Air Flow		
<b>Vertical Air Direction</b>		
	Enable use of bit-type objects (for Setting)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	Enable use of bit-type objects (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Centrally Control	Enable use of +/- object (for Setting)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Energy Saving Function		
Support Function	Enable use of Text object (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Specific status monitoring		
Scene		
Convertor Information		

### 5-4-2. DPT object type for Vertical Air Direction objects

This parameter changes the DPT setting of the 8-bit unsigned value Setting\_ and Monitoring\_ Vertical Air Direction object. For datapoints, Scaling and Enumerated are selectable.

- When “Enumerated” is selected, Setting\_ and Monitoring\_ Vertical Air Direction communication objects for this DPT will appear.

21	Inner_Setting_ Vertical Air Direction	1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Swing
77	Inner_Monitoring_ Vertical Air Direction	1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Swing

- When “Scaling” is selected, Setting\_ and Monitoring\_ Vertical Air Direction communication objects for this DPT will appear.

21	Inner_Setting_ Vertical Air Direction	0%-20% - Position 1; 21%-40% - Position 2; 41%-60% - Position 3; 61%-80% - Position 4; 81%-100% - Swing
77	Inner_Monitoring_ Vertical Air Direction	20% - Position 1; 40% - Position 2; 60% - Position 3; 80% - Position 4; 100% - Swing

Table next shows the range of values that can be sent through the Setting\_ object and the value returned by the Monitoring\_ object.

	Position 1	Position 2	Position 3	Position 4	Swing
Setting_	0% - 20%	21% - 40%	41% - 60%	61% - 80%	81% - 100%
Monitoring_	20%	40%	60%	80%	100%

### 5-4-3. Enable use of bit-type Vertical Air Direction objects (for setting)

This parameter shows/hides the bit-type Setting\_ Vertical Air Direction objects.

■ 22	Inner_Setting_Vertical Air Direction Pos1	1 - Position 1
■ 23	Inner_Setting_Vertical Air Direction Pos2	1 - Position 2
■ 24	Inner_Setting_Vertical Air Direction Pos3	1 - Position 3
■ 25	Inner_Setting_Vertical Air Direction Pos4	1 - Position 4
■ 26	Inner_Setting_Vertical Air Direction Swing	1 - Swing

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ Vertical Air Direction objects for Position 1, Position 2, Position 3, Position 4 and Swing will appear. To activate a vertical air direction by using these objects a “1” value has to be sent.

### 5-4-4. Enable use of bit-type Vertical Air Direction objects (for monitoring)

This parameter shows/hides the bit-type Monitoring\_ Vertical Air Direction objects.

■ 78	Inner_Monitoring_Vertical Air Direction Pos1	1 - Position 1
■ 79	Inner_Monitoring_Vertical Air Direction Pos2	1 - Position 2
■ 80	Inner_Monitoring_Vertical Air Direction Pos3	1 - Position 3
■ 81	Inner_Monitoring_Vertical Air Direction Pos4	1 - Position 4
■ 82	Inner_Monitoring_Vertical Air Direction Swing	1 - Swing


- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Monitoring\_ Vertical Air Direction objects for Position 1, Position 2, Position 3 and Position 4 will appear. When enabled, a vertical air direction will return a “1” through its bit-type object.

### 5-4-5. Enable use of +/- object for Vertical Air Direction (for setting)

This parameter shows/hides the Setting\_ Vertical Air Direction +/- communication object which lets change the indoor unit vertical air direction.

■ 27	Inner_Setting_Vertical Air Direction +/-	0 - Up; 1 - Down
------	--	------------------

- If set to “No” the object will not be shown.
- If set to “Yes” the Setting\_ Vertical Air Direction +/- object will appear.
- DPT type for +/- Vertical Air Direction Object  
The sequence followed when using this object is shown below:



### 5-4-6. Enable use of Text object for Vertical Air Direction (for Monitoring)

This parameter shows/hides the Monitoring\_ Vertical Air Direction Text communication object.

■ 83	Inner_Monitoring_Vertical Air Direction Text	ASCII String
------	--	--------------

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Vertical Air Direction Text object will appear.  
Also, in the parameters, will be shown five text fields, one for each vertical air direction, that will let modify the text string displayed by the Monitoring\_ Vertical Air Direction Text when changing vertical air direction.

Enable use of Text object (for Monitoring)  No  Yes

> String when vertical air direction is Position 1

> String when vertical air direction is Position 2

> String when vertical air direction is Position 3

> String when vertical air direction is Position 4

> String when vertical air direction is Swing

## 5-5. Horizontal Air Direction dialog

15.15.255 KNX Convertor for Indoor > Horizontal Air Direction

Mode	Enable use of Horizontal Air Direction object <input checked="" type="radio"/> No <input type="radio"/> Yes (for Setting and Monitoring)
Temperature	
Air Flow	
Vertical Air Direction	
<a href="#">Horizontal Air Direction</a>	
Centrally Control	
Energy Saving Function	
Support Function	
Specific status monitoring	
Scene	
Convertor Information	

All the parameters in this section are related with the different horizontal air direction properties and communication objects.



### 5-5-1. Enable use of Horizontal Air Direction objects (for Setting and Monitoring)

This parameter shows/hides the Setting\_ and Monitoring Horizontal Air Direction objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the 8-bit unsigned value Setting\_ and Monitoring\_ Horizontal Air Direction objects will appear. Also, the field to select the DPT setting and field to set the Horizontal Air Direction object setting will appear.

15.15.255 KNX Convertor for Indoor Unit > Horizontal Air Direction	
Mode	Enable use of Horizontal Air Direction object (for Setting and Monitoring) <input type="radio"/> No <input checked="" type="radio"/> Yes
Temperature	
Air Flow	DPT selection <input checked="" type="radio"/> Scaling <input type="radio"/> Enumerated
Vertical Air Direction	Enable use of bit-type objects (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
<b>Horizontal Air Direction</b>	Enable use of bit-type objects (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Centrally Control	Enable use of +/- object (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Energy Saving Function	
Support Function	Enable use of Text object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Specific status monitoring	
Scene	
Convertor Information	

### 5-5-2. DPT object type for Horizontal Air Direction objects

This parameter changes the DPT setting of the 8-bit unsigned value Setting\_ and Monitoring\_ Horizontal Air Direction object. For datapoints, Scaling and Enumerated are selectable.

- When “Enumerated” is selected, Setting\_ and Monitoring\_ Horizontal Air Direction communication objects for this DPT will appear.

■ 28 Inner_Setting_ Horizontal Air Direction	1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Position 5; 6 - Swing
■ 84 Inner_Monitoring_ Horizontal Air Direction	1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Position 5; 6 - Swing

- When “Scaling” is selected, Setting\_ and Monitoring\_ Horizontal Air Direction communication objects for this DPT will appear.

■ 28 Inner_Setting_ Horizontal Air Direction	0%-16% - Position 1; 17%-32% - Position 2; 33%-49% - Position 3; 50%-66% - Position 4; 67%-83% - Position 5; 84%-100% - Swing
■ 84 Inner_Monitoring_ Horizontal Air Direction	16% - Position 1; 32% - Position 2; 49% - Position 3; 66% - Position 4; 83% - Position 5; 100% - Swing

Table next shows the range of values that can be sent through the Setting\_ object and the value returned by the Monitoring\_ object.

	Position 1	Position 2	Position 3	Position 4	Position 5	Swing
Setting_	0% - 16%	17% - 32%	33% - 49%	50% - 66%	67% - 83%	84% - 100%
Monitoring_	16%	32%	49%	66%	83%	100%

### 5-5-3. Enable use of bit-type Horizontal Air Direction objects (for setting)

This parameter shows/hides the bit-type Setting\_ Horizontal Air Direction objects.

■	29	Inner_Setting_Horizontal Air Direction Pos1	1 - Position 1
■	30	Inner_Setting_Horizontal Air Direction Pos2	1 - Position 2
■	31	Inner_Setting_Horizontal Air Direction Pos3	1 - Position 3
■	32	Inner_Setting_Horizontal Air Direction Pos4	1 - Position 4
■	33	Inner_Setting_Horizontal Air Direction Pos5	1 - Position 5
■	34	Inner_Setting_Horizontal Air Direction Swing	1 - Swing

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ Horizontal Air Direction objects for Position 1, Position 2, Position 3, Position 4, Position 5 and Swing will appear. To activate a horizontal air direction by using these objects a “1” value has to be sent.

### 5-5-4. Enable use of bit-type Horizontal Air Direction objects (for monitoring)

This parameter shows/hides the bit-type Monitoring\_ Horizontal Air Direction objects.

■	85	Inner_Monitoring_Horizontal Air Direction Pos1	1 - Position 1
■	86	Inner_Monitoring_Horizontal Air Direction Pos2	1 - Position 2
■	87	Inner_Monitoring_Horizontal Air Direction Pos3	1 - Position 3
■	88	Inner_Monitoring_Horizontal Air Direction Pos4	1 - Position 4
■	89	Inner_Monitoring_Horizontal Air Direction Pos5	1 - Position 5
■	90	Inner_Monitoring_Horizontal Air Direction Swing	1 - Swing

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Monitoring\_ Horizontal Air Direction objects for Position 1, Position 2, Position 3, Position 4, Position 5 and Swing will appear. When enabled, a horizontal air direction will return a “1” through its bit-type object.

### 5-5-5. Enable use of +/- object for Horizontal Air Direction (for setting)

This parameter shows/hides the Setting\_ Horizontal Air Direction +/- communication object which lets change the indoor unit horizontal air direction.

■	35	Inner_Setting_Horizontal Air Direction +/-	0 - Up; 1 - Down
---	----	--	------------------

- If set to “No” the object will not be shown.
- If set to “Yes” the Setting\_ Horizontal Air Direction +/- object will appear.
- DPT type for +/- Horizontal Air Direction Object

The sequence followed when using this object is shown below:



### 5-5-6. Enable use of Text object for Horizontal Air Direction (for Monitoring)

This parameter shows/hides the Monitoring\_ Horizontal Air Direction Text communication object.

■	91	Inner_Monitoring_Horizontal Air Direction Text	ASCII String
---	----	--	--------------

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Horizontal Air Direction Text object will appear. Also, in the parameters, will be shown six text fields, one for each horizontal air direction, that will let modify the text string displayed by the Monitoring\_ Horizontal Air Direction Text when changing horizontal air direction.

Enable use of Text object (for Monitoring)  No  Yes

> String when horizontal air direction is Position 1

> String when horizontal air direction is Position 2

> String when horizontal air direction is Position 3

> String when horizontal air direction is Position 4

> String when horizontal air direction is Position 5

> String when horizontal air direction is Swing

## 5-6. Centrally Control dialog

15.15.255 KNX Converter for Indoor > Centrally Control

Mode	Enable use of Centrally Control objects (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	
Air Flow	Enable use of Centrally Control objects (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Vertical Air Direction	
Horizontal Air Direction	

**Centrally Control**

Energy Saving Function
Support Function
Specific status monitoring
Scene
Convertor Information

### 5-6-1. Enable use of bit-type Centrally Control objects (for setting)

This parameter shows/hides the bit-type Setting\_ Centrally Control objects.

36	Inner_Setting_Centrally Control (All Mode)	0 - Not inhibit; 1 - Inhibit
37	Inner_Setting_Centrally Control (Timer Mode)	0 - Not inhibit; 1 - Inhibit
38	Inner_Setting_Centrally Control (Set Temp)	0 - Not inhibit; 1 - Inhibit
39	Inner_Setting_Centrally Control (Operation Mode)	0 - Not inhibit; 1 - Inhibit
40	Inner_Setting_Centrally Control (On/Off Mode)	0 - Not inhibit; 1 - Inhibit
41	Inner_Setting_Centrally Control (On Mode)	0 - Not inhibit; 1 - Inhibit
42	Inner_Setting_Centrally Control (Filter Reset)	0 - Not inhibit; 1 - Inhibit

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ Centrally Control objects for All Mode, Timer Mode, Set Temp, Operation Mode, ON/OFF Mode, ON Mode and Filter Reset will appear. To activate a centrally control by using these objects a “1” value has to be sent.

## 5-6-2. Enable use of bit-type Centrally Control objects (for monitoring)

This parameter shows/hides the bit-type Monitoring\_ Centrally Control objects.

92	Inner_Monitoring_Centrally Control (All Mode)	0 - Not inhibit; 1 - Inhibit
93	Inner_Monitoring_Centrally Control (Timer Mode)	0 - Not inhibit; 1 - Inhibit
94	Inner_Monitoring_Centrally Control (Set Temperature)	0 - Not inhibit; 1 - Inhibit
95	Inner_Monitoring_Centrally Control (Operation Mode)	0 - Not inhibit; 1 - Inhibit
96	Inner_Monitoring_Centrally Control (On/Off Mode)	0 - Not inhibit; 1 - Inhibit
97	Inner_Monitoring_Centrally Control (On Mode)	0 - Not inhibit; 1 - Inhibit
98	Inner_Monitoring_Centrally Control (Filter Reset)	0 - Not inhibit; 1 - Inhibit

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Monitoring\_ Centrally Control objects for All Mode, Timer Mode, Set Temp, Operation Mode, ON/OFF Mode, ON Mode and Filter Reset will appear. When enabled, an centrally control will return a “1” through its bit-type object.

## 5-7. Energy Saving dialog

15.15.255 KNX Convertor for Indoor > Energy Saving Function

Mode	Enable use of Economy Mode objects (for Setting and Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	Enable use of Thermostat Off objects (for Setting and Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Air Flow	Enable use of Demand Control object (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Vertical Air Direction	Enable use of Human Detection objects (for Setting)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	Enable use of Human Detection objects (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes
Centrally Control	Enable use of Human Detection objects (for Monitoring)	<input checked="" type="radio"/> No <input type="radio"/> Yes

Energy Saving Function

Support Function
Specific status monitoring
Scene
Convertor Information

### 5-7-1. Enable use of Economy Mode objects (for Setting and Monitoring)

This parameter shows/hides the Setting\_ and Monitoring Economy Mode objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ and Monitoring\_ Economy Mode objects will appear. Sending “1” using the Setting\_ Economy Mode object enables Economy Mode. Sending “0” using the Setting\_ Economy Mode object disables Economy Mode. The Monitoring\_ Economy Mode object is “1” when Economy Mode is enabled. The Monitoring\_ Economy Mode object is “0” when Economy Mode is disabled.

44	Inner_Setting_Economy Mode Operation	0 - Normal operation; 1 - Save operation
100	Inner_Monitoring_Economy Mode Operation	0 - Normal operation; 1 - Save operation

### 5-7-2. Enable use of Thermostat Off objects (for Setting and Monitoring)

This parameter shows/hides the Setting\_ and Monitoring Thermostat Off objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ and Monitoring\_ Thermostat Off objects will appear.  
Sending “1” using the Setting\_ Thermostat Off object sets the Thermostat Off state. Sending “0” using the Setting\_ Thermostat Off object cancels the Thermostat Off state. The Monitoring\_ Thermostat Off object is “1” when the Thermostat Off state is set. The Monitoring\_ Thermostat Off object is “0” when the Thermostat Off state is not set.

145	Inner_Setting_Thermostat Off	0 - Release; 1 - Thermo-off
104	Inner_Monitoring_Thermostat Off	0 - Release; 1 - Thermo-off

### 5-7-3. Enable use of Demand Control object (for Monitoring)

This parameter shows/hides the Monitoring Demand Control object.

- If set to “No” the object will not be shown.
- If set to “Yes” the 8-bit unsigned value Monitoring\_ Demand Control object will appear.

105	Inner_Monitoring_Demand Control	0 - No operation; 1 - DRM 1; 2 - DRM 2; 3 - DRM 3
-----	---------------------------------	---

### 5-7-4. Enable use of Human Detection objects (for Setting)

This parameter shows/hides the Setting\_ Human Detection objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the Setting\_ Human Detection objects will appear.  
For the Setting\_ Human Detection object, sending “1” enables the human detection function, and sending “0” disables the human detection function. The Setting\_ Human Detection Time object sets the duration of time to wait before the human detection function starts operating.

46	Inner_Setting_Human Detection Auto Save	0 - No operation; 1 - Operation
47	Inner_Setting_Human Detection Auto Save Set Time	(minutes)
48	Inner_Setting_Human Detection Auto Off	0 - No operation; 1 - Operation
49	Inner_Setting_Human Detection Auto Off Time	(minutes)

### 5-7-5. Enable use of Human Detection objects (for Monitoring)

This parameter shows/hides the Monitoring\_ Human Detection objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the Monitoring\_ Human Detection objects will appear.  
The Monitoring\_ Human Detection object is “1” when the human detection function is enabled or “0” when the human detection function is disabled. The Monitoring\_ Human Detection Time object indicates the setting value for the duration of time to wait before the human detection function starts operating.

106	Inner_Monitoring_Human Detection Auto Save	0 - No operation; 1 - Operation
107	Inner_Monitoring_Human Detection Auto Save Set Time	(minutes)
108	Inner_Monitoring_Human Detection Auto Off	0 - No operation; 1 - Operation
109	Inner_Monitoring_Human Detection Auto Off Set Time	(minutes)

## 5-8. Additional Function dialog

15.15.255 KNX Converter for Indoor > Support Function	
Mode	Enable use of Filter Sign objects (for Setting and Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	
Air Flow	
Vertical Air Direction	
Horizontal Air Direction	
Centrally Control	
Energy Saving Function	
<b>Support Function</b>	
Specific status monitoring	
Scene	
Convertor Information	

### 5-8-1. Enable use of Filter Sign objects (for Setting and Monitoring)

This parameter shows/hides the Setting\_ and Monitoring Filter Sign objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ and Monitoring\_ Filter Sign objects will appear.  
 Sending “1” using the Setting\_ Filter Sign Reset object resets Filter Sign. (Sending “0” using it changes nothing.)  
 The Monitoring\_ Filter Sign object is “1” when there is any Filter Sign. The Monitoring\_ Filter Sign object is “0” when there is no Filter Sign.

43	Inner_Setting_Filter Sign Reset	0 - Not inhibit; 1 - Inhibit
99	Inner_Monitoring_Filter Sign	0 - No sign; 1 - Filter sign

## 5-9. Specific status monitoring dialog

15.15.255 KNX Converter for Indoor > Specific status monitoring	
Mode	Enable use of Defrosting object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	Enable use of Oil Recovery object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Air Flow	
Vertical Air Direction	Enable use of Pump Down object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	
Centrally Control	
Energy Saving Function	
Support Function	
<b>Specific status monitoring</b>	
Scene	
Convertor Information	

### 5-9-1. Enable use of Defrosting object (for Monitoring)

This parameter shows/hides the Monitoring\_ Specific Status Defrosting object.

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Specific Status Defrosting object will appear.  
The Monitoring\_ Specific Status Defrosting object is “1” in the case of the defroster-enabled state. The Monitoring\_ Specific Status Defrosting object is “0” in the case of the defroster-disabled state.

101 Inner\_Monitoring\_Specific Status Defrosting 0 - No defrosting status; 1 - Defrosting status

### 5-9-2. Enable use of Oil Recovery object (for Monitoring)

This parameter shows/hides the Monitoring\_ Specific Status Oil Recovery object.

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Specific Status Oil Recovery object will appear.  
The Monitoring\_ Specific Status Oil Recovery object is “1” in the case of the oil collection state. The Monitoring\_ Specific Status Oil Recovery object is “0” not in the case of the oil collection state.

102 Inner\_Monitoring\_Specific Status Oil Recovery 0 - No oil recovery status; 1 - Oil recovery status

### 5-9-3. Enable use of Pump Down object (for Monitoring)

This parameter shows/hides the Monitoring\_ Specific Status Pump Down object.

- If set to “No” the objects will not be shown.
- If set to “Yes” the Monitoring\_ Specific Status Pump Down object will appear.  
The Monitoring\_ Specific Status Pump Down object is “1” in the case of the pump failure state. The Monitoring\_ Specific Status Pump Down object is “0” not in the case of the pump failure state.

103 Inner\_Monitoring\_Specific Status Pump Down 0 - No pump down status; 1 - Pump down status

## 5-10. Scene Configuration dialog

15.15.255 KNX Convertor for Indoor > Scene

Mode	Enable use of scenes <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	
Air Flow	
Vertical Air Direction	
Horizontal Air Direction	
Centrally Control	
Energy Saving Function	
Support Function	
Specific status monitoring	
<b>Scene</b>	
Convertor Information	

All the parameters in this section are related with the Scene properties and communication objects.  
A scene contains values of: Operation Mode, Operation On/Off, Set Temperature, Airflow, Air Direction and Action time setting.

### 5-10-1. Enable use of scenes

This parameter shows/hides the scene configuration parameters and communication objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the scene parameters and communication objects will be shown.

15.15.255 KNX Convertor for Indoor > Scene	
Mode	Enable use of scenes <input type="radio"/> No <input checked="" type="radio"/> Yes
Temperature	Enable use of bit-type objects (for Setting) <input checked="" type="radio"/> No <input type="radio"/> Yes
Air Flow	
Vertical Air Direction	Scene 1 set <input checked="" type="radio"/> No <input type="radio"/> Yes
Horizontal Air Direction	
Centrally Control	Scene 2 set <input checked="" type="radio"/> No <input type="radio"/> Yes
Energy Saving Function	
Support Function	Scene 3 set <input checked="" type="radio"/> No <input type="radio"/> Yes
Specific status monitoring	
	Scene 4 set <input checked="" type="radio"/> No <input type="radio"/> Yes
<a href="#">Scene</a>	
<a href="#">Convertor Information</a>	

- 50 Inner\_Setting\_ Execute Scene 1 - Scene 1; 2 - Scene 2; 3 - Scene 3; 4 - Scene4; 5 - None
- 110 Inner\_Monitoring\_ Current Scene 1 - Scene 1; 2 - Scene 2; 3 - Scene 3; 4 - Scene4; 5 - None

### 5-10-2. Enable use of bit-type Scene objects (for setting)

This parameter shows/hides the bit-type Setting\_ Execute Scene objects.

- 51 Inner\_Setting\_ Execute Scene 1 1 - Execute Scene 1
- 52 Inner\_Setting\_ Execute Scene 2 1 - Execute Scene 2
- 53 Inner\_Setting\_ Execute Scene 3 1 - Execute Scene 3
- 54 Inner\_Setting\_ Execute Scene 4 1 - Execute Scene 4

- If set to “No” the objects will not be shown.
- If set to “Yes” the bit-type Setting\_ Execute Scene objects for Scene 1, Scene 2, Scene 3 and Scene 4 will appear. To execute a scene by using these objects, a “1” value has to be sent to the scene’s object we want to execute (i.e. to execute scene 4, a “1” has to be sent to the Setting\_ Execute Scene 4 object).



### 5-10-3. Scene “\*” set

This parameter lets define a set for a scene (the following description is valid for all the scenes).

- If set to “No” the set for the scene “\*” will be disabled.
- If set to “Yes” the set will be enabled. When a scene is executed the values configured in the preset will be applied.

Scene 1 set  No  Yes

Enable use of Action time  No  Yes

Value for Operation Mode

Value for Operation On/Off

Value for Set Temperature

Value for Airflow

Value for Vertical Air Direction

Value for Horizontal Air Direction

- Enable use of Action time

This specifies whether to set the duration of execution time to the scene.

When the execution time is set, the operation state before the scene is started is restored after the execution time elapses. (Fig 7. 10. 3)

- When this is set to “No”, the execution time setting is not applied.
- When this is set to “Yes”, the execution time setting field will appear.
- In the case of Yes, the values of Operation Mode, Operation On/Off, and Air Direction are not included in the scene.

Enable use of Action time  No  Yes

Action time for this scene (minutes)

Value for Set Temperature

Value for Airflow

In the execution time setting field, the Scene execution time can be set between 1 minute and 180 minutes.

Air-conditioner operation state




Figure 7-10-3. Operation during which execution times elapse

- Value for Operation Mode  
This parameter sets Operation Mode to apply when the scene is executed.  
The following options are available: "Auto", "Heat", "Cool", "Fan", "Dry" or "(unchanged)".
- Value for Operation On/Off  
This parameter sets Operation On/Off to apply when the scene is executed.  
The following options are available: "Off", "On" or "(unchanged)".
- Value for Set Temperature  
This parameter sets Set Temperature to apply when the scene is executed.  
The following options are available: from "10°C" to "32°C" or "(unchanged)".
- Value for Airflow  
This parameter sets Airflow to apply when the scene is executed.  
The following options are available: "Auto", "Quiet", "Low", "Med-Low", "Med", "Med-High", "High" or "(unchanged)".
- Value for Vertical Air Direction  
This parameter sets Vertical Air Direction to apply when the scene is executed.  
The following options are available: "Position 1", "Position 2", "Position 3", "Position 4", "Swing" or "(unchanged)".
- Value for Horizontal Air Direction  
This parameter sets Horizontal Air Direction to apply when the scene is executed.  
The following options are available: "Position 1", "Position 2", "Position 3", "Position 4", "Position 5", "Swing" or "(unchanged)".

## Note

- If any set value is configured as "(unchanged)", the execution of this scene will not change current status of this feature in the indoor unit.
- When a scene is executed, Monitoring\_ Current Scene object shows the number of this scene.  
Any change in previous items does Monitoring\_ Current Scene show "None".  
Only changes on items marked as "(unchanged)" will not disable current scene.

## 5-11. Converter Information dialog

15.15.255 KNX Converter for Indoor > Converter Information	
Mode	Enable use of Model Name object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Temperature	Enable use of Software Version object (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Air Flow	Enable use of Error Status objects (for Monitoring) <input checked="" type="radio"/> No <input type="radio"/> Yes
Vertical Air Direction	
Horizontal Air Direction	
Centrally Control	
Energy Saving Function	
Support Function	
Specific status monitoring	
Scene	

[Converter Information](#)

### 5-11-1. Enable use of Model Name object (for Monitoring)

This parameter shows/hides the Monitoring\_ Model Name object.

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Model Name object will appear.  
The Monitoring\_ Model Name object indicates the model name of the KNX converter.

■ ↕ 111 Convertor\_Monitoring\_Model Name Information ASCII String

### 5-11-2. Enable use of Software Version object (for Monitoring)

This parameter shows/hides the Monitoring\_ Software Version Information object.

- If set to “No” the object will not be shown.
- If set to “Yes” the Monitoring\_ Software Version Information object will appear.  
The Monitoring\_ Software Version Information object indicates the version of the KNX converter software.

■ ↕ 112 Convertor\_Monitoring\_Software Version Information ASCII String

### 5-11-3. Enable use of Error Status objects (for Monitoring)

This parameter shows/hides the Monitoring\_ Error Status objects.

- If set to “No” the objects will not be shown.
- If set to “Yes” the Monitoring\_ Error Status Error/No Error object and Monitoring\_ Error Status Error Code object will appear.  
The Monitoring\_ Error Status Error/No Error object is “1” when the converter is faulty. The Monitoring\_ Error Status Error/No Error object is “0” when the converter is running normally.  
The Monitoring\_ Error Status Error Code object indicates the code of the error that occurred in the converter.

■ ↕ 113 Convertor\_Monitoring\_Error Status Error/No Error 0 - No Alarm; 1 - Alarm  
■ ↕ 114 Convertor\_Monitoring\_Error Status Error Code (Error code section)(Error code subsection)

## 6 COMMUNICATION OBJECTS TABLE

Classification	FUNCTION	OBJECT NUMBER	NAME	LENGTH	DATAPOINT TYPE		FLAGS				Value	
					DPT_NAME	DPT_ID	R	W	T	U		
Control Object	Operation mode setting	1	Inner_Setting_Operation Mode [HVAC]	1 byte	DPT_HVACContrMode	20.105		W				0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
		2	Inner_Setting_Operation Mode	1 byte	DPT_Scaling	5.001		W				0%-20% - Auto; 21%-40% - Heat; 41%-60% - Cool; 61%-80% - Fan; 81%-100% - Dry
			Inner_Setting_Operation Mode	1 byte	DPT_Enumeration_1 (Operation Mode)			W				1 - Auto; 2 - Heat; 3 - Cool; 4 - Fan; 5 - Dry
		3	Inner_Setting_Operation Mode Auto	1 bit	DPT_Bool	1.002		W				1 - Auto
		4	Inner_Setting_Operation Mode Heat	1 bit	DPT_Bool	1.002		W				1 - Heat
		5	Inner_Setting_Operation Mode Cool	1 bit	DPT_Bool	1.002		W				1 - Cool
		6	Inner_Setting_Operation Mode Fan	1 bit	DPT_Bool	1.002		W				1 - Fan
		7	Inner_Setting_Operation Mode Dry	1 bit	DPT_Bool	1.002		W				1 - Dry
	8	Inner_Setting_Operation Mode +/-	1 bit	DPT_Step	1.007		W				0 - Up; 1 - Down	
	ON/OFF	9	Inner_Setting_Operation ON/OFF	1 bit	DPT_Switch	1.001		W				0 - Off; 1 - On
	Set temperature setting	10	Inner_Setting_Set Temperature	2 byte	DPT_Value_Temp	9.001		W				(°C)
		11	Inner_Setting_Set Temperature +/-	1 bit	DPT_Up-Down	1.008		W				0 - Up; 1 - Down
	Airflow setting	12	Inner_Setting_Airflow	1 byte	DPT_Scaling	5.001		W				0%-13% - Auto; 14%-27% - Quiet; 28%-41% - Low; 42%-55% - Med-Low; 56%-70% - Med; 71%-85% - Med-High; 86%-100% - High
			Inner_Setting_Airflow	1 byte	DPT_Enumeration_1 (Airflow)			W				1 - Auto; 2 - Quiet; 3 - Low; 4 - Med-Low; 5 - Med; 6 - Med-High; 7 - High
		13	Inner_Setting_Airflow Auto	1 bit	DPT_Bool	1.002		W				1 - Auto
		14	Inner_Setting_Airflow Quiet	1 bit	DPT_Bool	1.002		W				1 - Quiet
		15	Inner_Setting_Airflow Low	1 bit	DPT_Bool	1.002		W				1 - Low
		16	Inner_Setting_Airflow Med-Low	1 bit	DPT_Bool	1.002		W				1 - Med-Low
		17	Inner_Setting_Airflow Med	1 bit	DPT_Bool	1.002		W				1 - Med
		18	Inner_Setting_Airflow Med-High	1 bit	DPT_Bool	1.002		W				1 - Med-High
		19	Inner_Setting_Airflow High	1 bit	DPT_Bool	1.002		W				1 - High
		20	Inner_Setting_Airflow +/-	1 bit	DPT_Step	1.007		W				0 - Up; 1 - Down
	Vertical air direction position setting	21	Inner_Setting_Vertical Air Direction	1 byte	DPT_Scaling	5.001		W				0%-20% - Position 1; 21%-40% - Position 2; 41%-60% - Position 3; 61%-80% - Position 4; 81%-100% - Swing
			Inner_Setting_Vertical Air Direction	1 byte	DPT_Enumeration_1 (Vertical Air Direction)			W				1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Swing
		22	Inner_Setting_Vertical Air Direction Pos1	1 bit	DPT_Bool	1.002		W				1 - Position 1
		23	Inner_Setting_Vertical Air Direction Pos2	1 bit	DPT_Bool	1.002		W				1 - Position 2
		24	Inner_Setting_Vertical Air Direction Pos3	1 bit	DPT_Bool	1.002		W				1 - Position 3
25		Inner_Setting_Vertical Air Direction Pos4	1 bit	DPT_Bool	1.002		W				1 - Position 4	
26		Inner_Setting_Vertical Air Direction Swing	1 bit	DPT_Bool	1.002		W				1 - Swing	
27	Inner_Setting_Vertical Air Direction +/-	1 bit	DPT_Step	1.007		W				0 - Up; 1 - Down		

Classification	FUNCTION	OBJECT NUMBER	NAME	LENGTH	DATAPOINT TYPE		FLAGS				Value	
					DPT_NAME	DPT_ID	R	W	T	U		
Control Object	Horizontal air direction position setting	28	Inner_Setting_Horizontal Air Direction	1 byte	DPT_Scaling	5.001		W			0%-16% - Position 1; 17%-32% - Position 2; 33%-49% - Position 3; 50%-66% - Position 4; 67%-83% - Position 5; 84%-100% - Swing	
			Inner_Setting_Horizontal Air Direction	1 byte	DPT_Enumeration_1 (Horizontal Air Direction)			W			1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Position 5; 6 - Swing	
		29	Inner_Setting_Horizontal Air Direction Pos1	1 bit	DPT_Bool	1.002		W			1 - Position 1	
		30	Inner_Setting_Horizontal Air Direction Pos2	1 bit	DPT_Bool	1.002		W			1 - Position 2	
		31	Inner_Setting_Horizontal Air Direction Pos3	1 bit	DPT_Bool	1.002		W			1 - Position 3	
		32	Inner_Setting_Horizontal Air Direction Pos4	1 bit	DPT_Bool	1.002		W			1 - Position 4	
		33	Inner_Setting_Horizontal Air Direction Pos5	1 bit	DPT_Bool	1.002		W			1 - Position 5	
		34	Inner_Setting_Horizontal Air Direction Swing	1 bit	DPT_Bool	1.002		W			1 - Swing	
		35	Inner_Setting_Horizontal Air Direction +/-	1 bit	DPT_Step	1.007		W			0 - Up; 1 - Down	
	Remote controller operation prohibition setting		36	Inner_Setting_Centrally Control (All Mode)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
			37	Inner_Setting_Centrally Control (Timer Mode)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
			38	Inner_Setting_Centrally Control (Set Temp)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
			39	Inner_Setting_Centrally Control (Operation Mode)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
			40	Inner_Setting_Centrally Control (ON/OFF Mode)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
			41	Inner_Setting_Centrally Control (ON Mode)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
			42	Inner_Setting_Centrally Control (Filter Reset)	1 bit	DPT_Bool	1.002		W			0 - Not inhibit; 1 - Inhibit
	Filter sign reset		43	Inner_Setting_Filter Sign Reset	1 bit	DPT_Bool	1.002		W			0 - No change; 1 - Reset
	Economy mode		44	Inner_Setting_Economy Mode Operation	1 bit	DPT_Enable	1.003		W			0 - Normal operation; 1 - Save operation
	Thermo-off		45	Inner_Setting_Thermostat Off	1 bit	DPT_Bool	1.002		W			0 - Release; 1 - Thermo-off
	Human detection		46	Inner_Setting_Human Detection Auto Save	1 bit	DPT_Bool	1.002		W			0 - No operation; 1 - Operation
			47	Inner_Setting_Human Detection Auto Save Set Time	2 byte	DPT_Time-PeriodMin	7.006		W			(min)
			48	Inner_Setting_Human Detection Auto Off	1 bit	DPT_Bool	1.002		W			0 - No operation; 1 - Operation
			49	Inner_Setting_Human Detection Auto Off Time	2 byte	DPT_Time-PeriodMin	7.006		W			(min)
	Scene		50	Inner_Setting_Execute Scene	1 byte	DPT_Scene-Number	17.001		W			1 - Scene 1; 2 - Scene 2; 3 - Scene 3; 4 - Scene 4; 5 - None
			51	Inner_Setting_Execute Scene 1	1 bit	DPT_Bool	1.002		W			1 - Execute Scene 1
			52	Inner_Setting_Execute Scene 2	1 bit	DPT_Bool	1.002		W			1 - Execute Scene 2
			53	Inner_Setting_Execute Scene 3	1 bit	DPT_Bool	1.002		W			1 - Execute Scene 3
			54	Inner_Setting_Execute Scene 4	1 bit	DPT_Bool	1.002		W			1 - Execute Scene 4

Classification	FUNCTION	OBJECT NUMBER	NAME	LENGTH	DATAPOINT TYPE		FLAGS				Value
					DPT_NAME	DPT_ID	R	W	T	U	
Status Object	Operation mode	55	Inner_Monitoring_Operation Mode [HVAC]	1 byte	DPT_HVAC-ContrMode	20.105	R		T		0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
		56	Inner_Monitoring_Operation Mode	1 byte	DPT_Scaling	5.001	R		T		20% - Auto; 40% - Heat; 60% - Cool; 80% - Fan; 100% - Dry
			Inner_Monitoring_Operation Mode	1 byte	DPT_Enumeration_1 (Operation Mode)		R		T		1 - Auto; 2 - Heat; 3 - Cool; 4 - Fan; 5 - Dry
		57	Inner_Monitoring_Operation Mode Auto	1 bit	DPT_Bool	1.002	R		T		1 - Auto
		58	Inner_Monitoring_Operation Mode Heat	1 bit	DPT_Bool	1.002	R		T		1 - Heat
		59	Inner_Monitoring_Operation Mode Cool	1 bit	DPT_Bool	1.002	R		T		1 - Cool
		60	Inner_Monitoring_Operation Mode Fan	1 bit	DPT_Bool	1.002	R		T		1 - Fan
		61	Inner_Monitoring_Operation Mode Dry	1 bit	DPT_Bool	1.002	R		T		1 - Dry
		62	Inner_Monitoring_Operation Mode Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
	ON/OFF	63	Inner_Monitoring_Operation ON/OFF	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
	Set temperature	64	Inner_Monitoring_Set Temperature	2 byte	DPT_Value_Temp	9.001	R		T		(°C)
	Airflow status	65	Inner_Monitoring_Airflow	1 byte	DPT_Scaling	5.001	R		T		13% - Auto; 27% - Quiet; 41% - Low; 55% - Med-Low; 70% - Med; 85% - Med-High; 100% - High
			Inner_Monitoring_Airflow	1 byte	DPT_Enumeration_1 (Airflow)		R		T		1 - Auto; 2 - Quiet; 3 - Low; 4 - Med-Low; 5 - Med; 6 - Med-High; 7 - High
		66	Inner_Monitoring_Airflow Auto	1 bit	DPT_Bool	1.002	R		T		1 - Auto
		67	Inner_Monitoring_Airflow Quiet	1 bit	DPT_Bool	1.002	R		T		1 - Quiet
		68	Inner_Monitoring_Airflow Low	1 bit	DPT_Bool	1.002	R		T		1 - Low
		69	Inner_Monitoring_Airflow Med-Low	1 bit	DPT_Bool	1.002	R		T		1 - Med-Low
		70	Inner_Monitoring_Airflow Med	1 bit	DPT_Bool	1.002	R		T		1 - Med
		71	Inner_Monitoring_Airflow Med-High	1 bit	DPT_Bool	1.002	R		T		1 - Med-High
		72	Inner_Monitoring_Airflow High	1 bit	DPT_Bool	1.002	R		T		1 - High
73		Inner_Monitoring_Airflow Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String	
Indoor temperature	74	Inner_Monitoring_Room Temperature	2 byte	DPT_Value_Temp	9.001	R		T		(°C)	
Error monitoring	75	Inner_Monitoring_Error Status Error/No error	1 bit	DPT_Alarm	1.005	R		T		0 - No error; 1 - Error	
	76	Inner_Monitoring_Error Status Error Code	2 byte	DPT_Enumeration_2 (Error Code)		R		T		(Error code section)(Error code subsection)	

Classification	FUNCTION	OBJECT NUMBER	NAME	LENGTH	DATAPOINT TYPE		FLAGS				Value
					DPT_NAME	DPT_ID	R	W	T	U	
Status Object	Vertical air direction position status	77	Inner_Monitoring_Vertical Air Direction	1 byte	DPT_Scaling	5.001	R		T		20% - Position 1; 40% - Position 2; 60% - Position 3; 80% - Position 4; 100% - Swing
			Inner_Monitoring_Vertical Air Direction	1 byte	DPT_Enumeration_1 (Vertical Air Direction)	R		T		1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Swing	
		78	Inner_Monitoring_Vertical Air Direction Pos1	1 bit	DPT_Bool	1.002	R		T		1 - Position 1
		79	Inner_Monitoring_Vertical Air Direction Pos2	1 bit	DPT_Bool	1.002	R		T		1 - Position 2
		80	Inner_Monitoring_Vertical Air Direction Pos3	1 bit	DPT_Bool	1.002	R		T		1 - Position 3
		81	Inner_Monitoring_Vertical Air Direction Pos4	1 bit	DPT_Bool	1.002	R		T		1 - Position 4
		82	Inner_Monitoring_Vertical Air Direction Swing	1 bit	DPT_Bool	1.002	R		T		1 - Swing
		83	Inner_Monitoring_Vertical Air Direction Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
Horizontal air direction position status	84	Inner_Monitoring_Horizontal Air Direction	1 byte	DPT_Scaling	5.001	R		T		16% - Position 1; 32% - Position 2; 49% - Position 3; 66% - Position 4; 83% - Position 5; 100% - Swing	
		Inner_Monitoring_Horizontal Air Direction	1 byte	DPT_Enumeration_1 (Horizontal Air Direction)	R		T		1 - Position 1; 2 - Position 2; 3 - Position 3; 4 - Position 4; 5 - Position 5; 6 - Swing		
	85	Inner_Monitoring_Horizontal Air Direction Pos1	1 bit	DPT_Bool	1.002	R		T		1 - Position 1	
	86	Inner_Monitoring_Horizontal Air Direction Pos2	1 bit	DPT_Bool	1.002	R		T		1 - Position 2	
	87	Inner_Monitoring_Horizontal Air Direction Pos3	1 bit	DPT_Bool	1.002	R		T		1 - Position 3	
	88	Inner_Monitoring_Horizontal Air Direction Pos4	1 bit	DPT_Bool	1.002	R		T		1 - Position 4	
	89	Inner_Monitoring_Horizontal Air Direction Pos5	1 bit	DPT_Bool	1.002	R		T		1 - Position 5	
	90	Inner_Monitoring_Horizontal Air Direction Swing	1 bit	DPT_Bool	1.002	R		T		1 - Swing	
	91	Inner_Monitoring_Horizontal Air Direction Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String	
Remote controller operation prohibition setting status	92	Inner_Monitoring_Centrally Control (All Mode)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
	93	Inner_Monitoring_Centrally Control (Timer Mode)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
	94	Inner_Monitoring_Centrally Control (Set Temperature)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
	95	Inner_Monitoring_Centrally Control (Operation Mode)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
	96	Inner_Monitoring_Centrally Control (ON/OFF Mode)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
	97	Inner_Monitoring_Centrally Control (ON Mode)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
	98	Inner_Monitoring_Centrally Control (Filter Reset)	1 bit	DPT_Bool	1.002	R		T		0 - Not inhibit; 1 - Inhibit	
Filter sign status	99	Inner_Monitoring_Filter Sign	1 bit	DPT_Bool	1.002	R		T		0 - No sign; 1 - Filter sign	
Economy mode	100	Inner_Monitoring_Economy Mode Operation	1 bit	DPT_Enable	1.003	R		T		0 - Normal operation; 1 - Save operation	

Classification	FUNCTION	OBJECT NUMBER	NAME	LENGTH	DATAPOINT TYPE		FLAGS				Value
					DPT_NAME	DPT_ID	R	W	T	U	
Status Object	Special status monitoring	101	Inner_Monitoring_Specific Status Defrosting	1 bit	DPT_Bool	1.002	R		T		0 - No defrosting status; 1 - Defrosting status
		102	Inner_Monitoring_Specific Status Oil Recovery	1 bit	DPT_Bool	1.002	R		T		0 - No oil recovery status; 1 - Oil recovery status
		103	Inner_Monitoring_Specific Status Pump Down	1 bit	DPT_Bool	1.002	R		T		0 - No pump down status; 1 - Pump down status
	Thermo-off	104	Inner_Monitoring_Thermostat Off	1 bit	DPT_Bool	1.002	R		T		0 - Release; 1 - Thermo-off
	Demand	105	Inner_Monitoring_Demand Control	1 byte	DPT_Value_1_Ucount	5.010	R		T		0 - No operation; 1 - DRM 1; 2 - DRM 2; 3 - DRM 3
	Human detection	106	Inner_Monitoring_Human Detection Auto Save	1 bit	DPT_Bool	1.002	R		T		0 - No operation; 1 - Operation
		107	Inner_Monitoring_Human Detection Auto Save Set Time	2 byte	DPT_Time-PeriodMin	7.006	R		T		(min)
		108	Inner_Monitoring_Human Detection Auto Off	1 bit	DPT_Bool	1.002	R		T		0 - No operation; 1 - Operation
		109	Inner_Monitoring_Human Detection Auto Off Set Time	2 byte	DPT_Time-PeriodMin	7.006	R		T		(min)
	Scene	110	Inner_Monitoring_Current Scene	1 byte	DPT_Scene Number	17.001	R		T		1 - Scene 1; 2 - Scene 2; 3 - Scene 3; 4 - Scene4; 5 - None;
	Convertor Information	111	Convertor_Monitoring_Model Name Information	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
		112	Convertor_Monitoring_Software Version Information	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
	Error monitoring	113	Convertor_Monitoring_Error Status Error/No Error	1 bit	DPT_Alarm	1.005	R		T		0 - No Alarm; 1 - Alarm
		114	Convertor_Monitoring_Error Status Error Code	2 byte	DPT_Enumeration_2 (Error Code)		R		T		(Error code section)(Error code subsection)